

# VW DIAGNOSTIC FUNCTION LIST V20.00

year	system type	system	function
		01 Engine electronics	
		11 Engine electronics 2	
		21 Engine electronics 3	
		02 Transmission Electronics	
		03 Brake Electronics	
		08 AC/Heating electronics	
		25 Immobilizer	
		47 Soundsystem	
		12 Clutch electronics	
		34 Self leveling suspension	
		15 Airbags	
		16 Steering Wheel Electronics	
		44 Steering assistance	
		35 Central Locking	
		14 Wheel damping electronics	
		17 Instrument Cluster	
		18 Aux heating	
		13 Distance control	
		19 Gateway data bus	
		26 Electric roof control	
		29 Left light control	
		39 Right light control	
		37 Navigation	
		45 Interior Monitoring	
		46 Central Control Module	
		49 Auto. Lighting switch	
		51 Electric drive	
		61 Battery control	
		75 Emergency call module	
		76 Parking aid	
		09 Electronic Ctrl Electronics	
		22 4WD Electronics	
		24 Drive slip control	
		36 Driver's side seat adj.	Control Unit Info
		41 Diesel pump electronics	Read Fault Codes
		55 Headlight range control	Measuring Blocks (Live Data)
		56 Radio	Clear Fault Codes
		65 Type pressure monitoring	Basic Settings
	without CAN bus	66 Seat-/mirror adjust.	Adaptation
		71 Battery charger	Single Reading
		42 DRIVER-DOOR ELECT.	Output Tests
		52 PASSE.-DOOR ELECT.	Code Module
		62 LR-DOOR ELECTRONI.	Login
		72 RR-DOOR ELECTRONI.	Chassis Number adjustment
		23 BRAKER BOOSTER	Readiness
		43 BRAKER BOOST. ASS1.	
		63 DRVS BOARDING ASS1	
		73 DRVS BOARDING ASS2	
		54 Rear spoiler	
		05 ACCESS & PERMISSI.	
		06 PASSENE. SEAT ADJ.	
		07 DISPLAY-/CNTL UNIT	
		27 DIS./CTL UNIT REAR	
		57 TV-TUNER	
		67 VOICE CONTROL	
		77 TELEPHONE	
		38 ROOF ELECTRONICS	
		48 DRVS SEAT ADJ. REAR	
		68 WIPER ELECTRONICS	
		78 SLIDING DOOR	
		59 TOWING PROTECTION	
		69 TRAILER FUNCTION	
		28 Climate Control Unit Rear	
		31 Engine Electronics Conjunct.	
		32 Locking Electronics	
		53 Parking Brake	
		58 Auxiliary Fuel Tank	
		64 Stabilizers	
		1C Vehicle Position Detection	
		2D Voice Amplification	
		3D Special Function	
		6E Roof Display/Control Head	
		7E Ind.Unit in Inst.Panel Ins.	
		0D Sliding Door Left	
		7D Auxiliary Heater	
		0F Radio Tuner-Digital	
		1F Radio Satellite	
		2F TV Tuner-Digital	
before 2005			

with CAN bus	01 Engine electronics	Control Unit Info Read Fault Codes Measuring Blocks (Live Data) Clear Fault Codes Basic Settings
	11 Engine electronics2	
	44 Steering assistance	
	05 ACCESS & PERMISSI.	
	21 Engine electronics3	
	31 Engine Electronics Conjunct.	
	61 Battery control	
	02 Transmission Electronics	
	22 4WD Electronics	
	42 DRIVER-DOOR ELECT.	
	52 PASSE.-DOOR ELECT.	
	62 LR-DOOR ELECTRONI.	
	72 RR-DOOR ELECTRONI.	
	03 Brake Electronics	
	13 Distance control	
	53 Parking Brake	
	34 Self leveling suspension	
	15 Airbags	
	25 Immobilizer	
	55 Headlight range control	
	65 Tyre pressure monitoring	
	75 Emergency call module	
	06 PASSENE. SEAT ADJ.	
	16 Steering Wheel Electronics	
	26 Electric roof control	
	36 Driver's side seat adj.	
	46 Central Control Module	
	56 Radio	
	66 Seat-/mirror adjust.	
	76 Parking aid	
	1D Driver idnetify	
	3D Special Function	
	07 DISPLAY-/CNTL UNIT	
	17 Instrument Cluster	
	37 Navigation	
	47 Soundsystem	
57 TV-TUNER		
67 VOICE CONTROL		
77 TELEPHONE		
0E Media Player 1		
1E Media Player 2		
2E Media Player 3		
3E Media Player 4		
4E RR Control unit		
5E LR Control unit		
7E Insrtument Cluster Display Unit		
08 AC/Heating electronics		
18 Aux heating		
28 Climate Control Unit Rear		
38 ROOF ELECTRONICS		
7D Auxiliary Heater		
09 Electronic Ctrl Electronics		
19 Gateway data bus		
69 TRAILER FUNCTION		
0F Radio Tuner-Digital		
1F Radio Satellite		
2F TV Tuner-Digital		
4F Central Electronics 2		