

ZhongHua Car special Diagnostic Program (V11.00)

VEHICLE MODEL	DLC Location	Connector	System	Read DTC	Clear DTC	Data Stream	Actuation Test	System Status	Version Information	Other Function	
4G63	Under deshpanel	[Zhonghua-16]	MM MPI engine	√	√	√	√		√	Self adaptation	
			Mitsubishi engine	√	√	√	√				
			Delphi (Europe 3)System	√	√	√	√	√	√		
			AT	√	√	√	√				
			ABS	√	√	√	√	√	√		Exit System
			SRS(pre-tension):	√	√					√	
			SRS (pre-tension +front airbag)	√	√					√	
4G64			Mitsubishi immobilizer	√	√	√					key matching
			MM MPI engine	√	√	√	√			√	Self adaptation
			Mitsubishi engine	√	√	√	√				
			Delphi (Europe 3)System	√	√	√	√	√	√		
			AT	√	√	√	√				
			ABS	√	√	√	√	√	√		Exit System
			ABS (ISO)	√	√	√	√	√	√	√	Controller coding, Charging and exhaust, Exit
1.8T			SRS(pre-tension):	√	√					√	
			SRS (pre-tension +front airbag)	√	√					√	
			Mitsubishi immobilizer	√	√	√					Key matching
			Siemens engine	√	√	√	√			√	Read data stream of immobilizer
			AT	√	√	√					
			ABS	√	√	√	√			√	Controller coding, Charging and exhaust, Exit
			SRS	√	√					√	